


ELETEK

SENSING | CONTROLLING | TECHNOLOGY







NEAREST VALUE



ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

WATER LEVEL SENSOR



**CUSTOMIZE
Are Available**

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

WATER LEVEL SENSOR

ELETEK



Single Level Switch



✓ SPST ✓ SPDT

HK-HFS-B



✓ SPST ✓ SPDT

HK-HFS-HB



✓ SPST ✓ SPDT

HK-HFS-C



✓ SPST ✓ SPDT

HK-HFS-PP



✓ SPST ✓ SPDT

HK-VFS-L-SS



✓ SPST ✓ SPDT

HK-HFS-F



✓ SPST ✓ SPDT

HK-MVFS-SS



✓ SPST ✓ SPDT

HK-MVFS-PP

4

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

WATER LEVEL SENSOR



Multi Level Switch & Float Valve



HK-VFS-2L-1F



HK-VFS-L-2L-1F



HK-VFS-2L-2F-Adj



HK-VFS-4L-4F



HK-Float Valve



HK-Conductivity Level Switch

Level Indication & Switching



Side Arm + Float S/W



Top Mount



Magnetic Coupled

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

TEMPERATURE SENSOR'S

ELETEK



Thermocouple Sensors



✓ "J" ✓ "K"

HK-Spring Loaded



✓ "J" ✓ "K"

HK-Bolt In - L Bend



✓ "J" ✓ "K"

HK- Clamp Pencil - L Bend




✓ "J" ✓ "K"

HK-Spring Loaded - L Bend



✓ "J" ✓ "K"

HK-Bolt In



✓ "J" ✓ "K"

HK-Washer



✓ "J" ✓ "K"

HK-Holder Rotating



✓ "J" ✓ "K"

HK-Nozzle



✓ "J" ✓ "K"

HK- Lugs



✓ "J" ✓ "K"

HK-Spring Rotating



✓ "J" ✓ "K"

HK-Nozzle Long Tip



✓ "J" ✓ "K"

HK- Push In



✓ "J" ✓ "K"

HK- Spring Adjustable



✓ "J" ✓ "K"

HK- LBF Nozzle



✓ "J" ✓ "K"

HK- Straight Pencil

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

TEMPERATURE SENSOR'S



Special Thermocouple Sensors



✓ "J" ✓ "K"

HK-Thermowell Bolt In



✓ "J" ✓ "K"

HK-Air Sensor



✓ "J" ✓ "K"

HK-Clamp On



✓ "J" ✓ "K"

HK-Head Sensor



✓ "R" ✓ "S"

HK-PT/PT/RH-High Temp



HK-Bare Junction



✓ "J" ✓ "K"

HK-Bolt In - MI Sensor



✓ "J" ✓ "K"

HK-MI Sensor



✓ "J" ✓ "K"

HK-QRT

RTD Sensor



✓ Simplex ✓ Duplex

HK-Straight Pencil



HK-Bolt In-Duplex



HK-Bolt In-Simplex



✓ Simplex ✓ Duplex

HK-Head Sensor-Bolt In



✓ Simplex ✓ Duplex

HK-Head Sensor-Sanitary



✓ Simplex ✓ Duplex

HK-Spring Loaded

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

CR/AL (K TYPE)

TEMPERATURE SENSOR'S



**CUSTOMIZE
Are Available**

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

TEMPERATURE SENSOR'S

RTD (PT-100)



ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033



HUMIDITY SENSOR

Input : +5V DC

Output : 0 To 3.3V (3Wire)

Humidity Range: 0 To 95%rH

Working Temperature : -20 To 60°C



HUMIDITY SENSOR

Input : +5V DC

Output : 0 To 3.3V (4 Wire)

Humidity Range: 0 To 100%rH

Working Temperature : -40 To 70°C



HUMIDITY SENSOR

Input : +24V DC

Output : 4 To 20mA (2 Wire)

Humidity Range: 0 To 100%rH

Working Temperature : -40 To 125°C



TEMPERATURE + HUMIDITY SENSOR (Duck Mount)

Input : +24V DC

Output : 4 To 20mA (3 Wire)

Humidity Range: 0 To 100%rH

Temperature Range : -40 To 125°C

ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033

HUMIDITY SENSOR

Temperature + Humidity Sensor (RS-485 Output)

Input : +12V DC

Output : RS-485

Humidity Range: 0 To 99.9%rH

Temperature Range : -40 To 70'C



OTHER'S



Humidity Sensor

Temperature + Humidity Sensor

Co2 SENOR

AIR FLOW SENSOR



ELETEK ENTERPRISES

301,309,3rd Floor, Laxmi Tower, C-1/3 Naniwala Bagh,
Azadpur Delhi, North West Delhi, Delhi, 110033